



LET'S
CONNECT

INTERNATIONAL
PRINECT USER DAYS



Prinect Multicolor

For experts.



Prinect Multicolor

Have a look behind the scene!



Workshop no. 19 – Prinect Multicolor for Experts

Presentation

Cordula Voelker

Tobias Laubmann

Prinect Cockpit

Moana Diehl

Tobias Laubmann

Speedmaster XL 75-8-P

Roland Schönmann


Mustafa Elshakarji

Prinect Multicolor for Experts




1. How good is color quality with Prinect Multicolor?

Printing with XL 75-8-P




2. Conditions for Prinect Multicolor Color management



3. Expert level news


InRip color management – ROOM Proof – mixed rendering - mixed screening






Prinect Multicolor - What is it?

Printing with 7 inks



→ Process colors BCMY + spot colors violet, green and orange.

→ Simulating a huge amount of other spot colors






Prinect Multicolor - What about color quality?

Printed with one spot color

100 %





Pantone® color



$\Delta E = ?$


Printed with Multicolor separation






How good is color quality with Prinect Multicolor?

Simulation of color fan Pantone® solid coated V4: **2161** colors



Simulating Spot Colors with Prinect Multicolor



2161 colors

94 % $\leq \Delta E 3$

98 % $\leq \Delta E 5$

simulated PANTONE® 3165_C	27,67	-30,2	-16,27	0,26
simulated PANTONE® 7709_C	67,26	-23,4	-14,26	1,33
simulated PANTONE® 7710_C	61,09	-36	-20,41	1,49
simulated PANTONE® 7711_C	54,02	-44,06	-24,32	0,93
simulated PANTONE® 7712_C	47,6	-40,32	-26,36	0,95
simulated PANTONE® 7713_C	44,43	-41,72	-21,11	0,81
simulated PANTONE® 7714_C	42,37	-39,52	-18,06	0,77
simulated PANTONE® 7715_C	35,4	-31,63	-14,41	0,43
simulated PANTONE® 2218_C	67,5	-18,11	-14,7	1,68
simulated PANTONE® 2219_C	62,57	-20,06	-16,64	1,20
simulated PANTONE® 2220_C	57,43	-21,46	-18,44	1,29
				number of colors
< dE 3.0				2022
< dE 5.0				2128
				$\Delta E 2000$
				93,6%
				98,5%



Print form 1 „Passion“



1st spot color




2nd spot color



Print form 1 „Passion“

6 separations for printing with Multicolor



Benefits with Prinect Multicolor



→ Less wash-up times:

→ Reduced makeready waste:

→ Repeatable print quality:

→ Reduced ink inventory:

No ink change

Stable color control

Standardized Multicolor process

Only 7 inks






Color Management for Prinect Multicolor




Prepress



Plate setter




Press






Print form 2 „Lotea“




1st spot color




2nd spot color



3rd spot color



4th spot color



5th spot color



Print form 2 „Lotea“

7 separations for printing with Multicolor



Multicolor InRIP Color Management




Princt Production

Version 2021

© Copyright 2020 Heidelberger Druckmaschinen AG. All Rights reserved.
Heidelberg, the Heidelberg logo, Princt and the Princt logo are registered trademarks of Heidelberger Druckmaschinen AG in the U.S. and other countries.
Further information about trademarks, copyrights and third party acknowledgments can be found in the Info dialog.

HEIDELBERG

Room Proof – Color Proof



Room Proof

= Rip once output many

- proves the content
- possible for InRIP color management


Color Proof

= 4c + spot colors

- proves the color – is color binding


Rendering Intents - Absolute vs. Relative

Original gamut – white substrate



● Three different colors ●


Target (yellowish) substrate



○ ○ ○ Rendering intent Absolute
 ● ● ● Rendering intent Relative

Mixed Rendering Intent

IT874_isoCoatedV2_to_7C-
DarkCardboard_abs_vs_mixed



Heidelberg Patent

Goal:

- Optimize printing on dark cardboard ($L < 90$)

Solution:

- Use a mix of 2 rendering intents: absolute + relative


Green strokes

= difference in color space comparing absolute versus mixed rendering intent



Three-dimensional Color Space

MC-ICC Profile
Pantone® v4



Color space comparison

- Blue: Multicolor
- Yellow: Pantone® V4 spot colors

Mixed Screening



Multicolor-Systeme | Lentikular Systeme | Sonstiges

System Name: AM_FM_ICC Device Name: Suprasetter

Farbsystem: ICC Profil | ICC Profil Profil: \\wieapp01122\PTConfig\SysConfig\Resources\ICC-Profiles\Printer\MultiColor\Auftragsspezifisch\323247_Praktikum_Boqi\GC2\MC7_GC2_Karton_V3

Multicolor-Tabelle:

Farbe	CMYK	Winkel [°]	Feinheit	Typ
Cyan		172,5	1	AM
Magenta		52,5	1	AM
Yellow		7,5	1,06	AM
Black		112,5	1	AM
ORANGE				FM Fine
GREEN				FM Fine
BLUE				FM Fine
Default Spot				FM Fine

Verfügbare AM Raster:

Rasterfeinheit: 1 Winkel: 120

Verfügbare FM Raster:


Starter Medium Fine

6 4

Freiquenzen | Speichern als ... | Speichern | Schließen



How can we achieve a bigger gamut? Low density (SD) versus high density (HD)



Potential Problem:

Pantone[®] 300

- MC separation = 100% Cyan, 50% Violet, 15% Black
- Delta E above 3.5
- more Cyan needed


Solution:

- MC separation = 120% Cyan, 50% Violet, 15% Black






How can we achieve a bigger gamut? SD versus HD





Why SCTV? Pantone Reflex Blue - Hooking

Set of measurements of Reflex Blue in CIELAB



Steve Smiley


Problems:

1. Different methods are used to measure spot colors
2. Curvature is not taken into account by display of intermediate tones

-> Displayed colors can differ from printed result



Why SCTV? Murray Davies' calculation



Steve Smiley

Murray Davies' calculation

- Distance of dots is not equidistant
- Intermediate tones cannot be estimated by linear interpolation in CIELAB

SCTV – Spot Color Tone Value

- Visual equidistant distinction
- Can also be used for CMYK (Black would look darker)
- SCTV spot color tone value is implemented in ISO 20654

Prinect Multicolor with Heidelberg



Seven - color offset printing process

Heidelberg is your full end to end solution provider



Prinect Multicolor

Have a look behind the scene!